User's Manual

Digital Music Player

TS8GMP330W/P/K

Transcend®

Table of Contents

Introduction | 5
Package Contents | 5
Features | 7
System Requirements | 7
Safety Precautions | 8
- General Use 8
- Backing up Data 8
- Caution: Risk of Deafness 8
- Reminders 9

Player Controls | 10
Music Playback Screen | 11
Basic Operation | 12
- Charging the Battery 12
- Power ON 12
- Power Off 12
- Play a Song 13
- Pause a Song 13
- Next Track 13
- Previous Track 13
- Fast Forward 13
- Rewind 13
- Increase Volume 13
- Decrease Volume 13
- Back / Main Menu 13
- Hold 13
- Reset 13

MUSIC Mode | 14
- Playing Audio Files 14
- Repeat Mode 14
- EQ Mode 15
- SRS WOW MODE 16
- A-B Repeat 16
- Adding a Song to My Playlist 17
- Lyrics Sync 17
- Delete 17
- My Playlists 18
- Import Playlist (*.m3u) 19

- Playlist Playback (*.m3u) 21
- File Navigator 22

RADIO Mode | 23

- Listening to the Radio 23
- Selecting a Radio Station 23
- Recalling a Saved Station 23
- Recording the Radio 23
- Channel List 24
- Save Station 24
- Delete 24
- Delete All 24
- Auto Search 24
- FM Band 25

RECORD Mode | 26

- Voice Recording 26
- Line-in Recording 27
- FM Radio Recording 27

Settings | 28

- Record Source 28
- Record Quality 28
- Power Saving 28
  - Sleep Timer 28
  - Auto Power Off 29
- Display 29
  - Screen Saver 29
  - Contrast 30
- Volume Limit 30
- Date / Time Settings 30
- Language 31
- Player Info 31

Driver Installation | 32

- Driver Installation for Windows®2000, XP and Vista 32
- Driver Installation for Mac® OS 10.0 or Later 32
- Driver Installation for Linux® Kernel 2.4 or Later 32

Connecting to a Computer | 33

- Transferring Files to the MP330 33

Disconnecting from a Computer 35

Troubleshooting | 36

Specifications | 38

Ordering Information | 38
Recycling & Environmental Considerations | 39
Transcend Limited Warranty | 40

Introduction |

Thank you for purchasing Transcend's **MP330**, a next-generation MP3 Player that combines all the advantages of lightweight portable music with the benefits of a USB flash drive, and includes many extra features such as an FM radio, voice recording, direct Line-In recording, karaoke-style lyrics display, and A-B repeat functions. Your MP330 is equipped with a High-speed USB 2.0 interface to transfer data and music files to and from your computer quickly and easily. The A-B repeat feature allows you to continuously replay specific sections of an audio file – ideal for learning foreign languages and reviewing an important part of a song or recording. In addition, you can make personal memos and record meetings or class lectures using the voice recorder with the built-in microphone. The stylish MP330 from Transcend will change the way you think about digital music forever.

Package Contents |

The MP330 package includes the following items:

- MP330

- Sport Clip

- Earphones

- Line-In Recording Cable

- Quick Start Guide

Features |

- Supports MP3, WMA and WAV music files
- Vivid all-white OLED screen displays clear text at any angle and in any light
- Recordable FM Radio with 20 station presets
- Built-in microphone and direct Line-In recording (for CD players, or other devices)
- Playlist Builder
- Karaoke-style synchronized lyrics display
- A-B repeat allows continuous replay of a designated section of a track
- Supports 13 languages including menus, song/album title, artist name and lyrics
- USB flash drive capabilities for data transfer and storage
- Adjustable sleep timer
- Power-saving screen savers and auto-shutoff function
- 8 Equalizer effects, including a customizable USER EQ setting
- Internal Li-polymer battery provides up to 12 hours of continuous music playback*
- Built-in USB 2.0 connector for easy computer connectivity and fast file transfers
- Time and date display

  * Max. playback time achieved with screen saver set to “10-Sec/Blank” and “Lyrics Sync” disabled.

System Requirements |

- A desktop or notebook computer with a working USB port
- One of following operating systems:
  - Windows® 2000
  - Windows® XP
  - Windows Vista®
  - Windows® 7
  - Mac® OS 10.0 or later
  - Linux® Kernel 2.4 or later

Safety Precautions

These usage and safety guidelines are **IMPORTANT!** Please follow them carefully.

General Use

- Unpack the contents of the MP330 package carefully.
- Ensure USB connectors are the same size and shape before connecting – never force them
- Always use the Transcend-provided power adapters and cables. Using incompatible cables may permanently damage your MP330.
- Never connect the MP330 to a USB hub. USB hubs connect to multiple devices at the same time, resulting in inadequate or unstable power supply. **This may cause damage to your digital music player.** Known problems caused by connecting to a USB hub include reduced playback time, random resets, and in the worst case, permanent damage to the player's firmware.
- Do not allow your MP330 to get wet or come in contact with water or any other liquids
- Do not use a damp/wet cloth to wipe or clean the exterior case.
- Do not use or store your MP330 in any of the following environments:
    - Direct sunlight
    - Next to an air conditioner, electric heater or other heat sources
    - In a closed car that is in direct sunlight
- Always unplug the player once it is fully charged. Avoid charging the player for more than 12 hours.
- Do not charge in high-temperature environments or while exposed to direct sunlight.
- To maintain battery health, be sure to complete at least one full discharge/charge cycle per month.

Backing up Data

- **Transcend does NOT take any responsibility for data loss, or damage during operation**. If you decide to store data on your MP330 we strongly advise that you regularly backup the data to a computer, or other storage medium.
- To ensure High-Speed USB 2.0 data transfer rates when connecting to a computer, please ensure the computer has the necessary USB drivers installed. If you are unsure how to check this, please consult your computer or motherboard User's Manual for USB driver information.

Caution: Risk of Deafness

- Repeated or regular use of headphones or earphones at volume levels above 80 decibels can give a false impression that the audio level is not high enough. Users may try to progressively increase the volume control, therefore risking a dangerous noise level for their ears.
- To protect your health and your hearing, keep the volume of your MP3 player below 80 decibels and do not use for an extended period of time. Stop use if symptoms like headaches, nausea, or hearing disorders occur.
- Your MP3 player is limited to a volume level of 100 decibels.

- Both the MP3 player and its accompanying earphones are compliant with the French regulation concerning musical Walkmans (24th July 1998 Order).
- Before using any other earphones, confirm that their technical specifications are compatible with the original set.

Reminders

- Make sure the

switch is not enabled before turning on the player.
- If you leave the digital music player plugged into a notebook computer that is running on battery power, the player will gradually drain power from your notebook's battery.
- Follow the procedures in the "Disconnecting from a Computer" section to properly remove your MP330 from a computer.
- Transcend occasionally releases firmware updates for certain products. We suggest you visit http://www.transcend-info.com and download the latest firmware version for your device.

Player Controls



A	High-speed USB 2.0 Connector	
B	White Monochrome OLED Display	
C	● \ •••	Options / Record
D		Back / Main Menu
E	◂HOLD	Hold Switch
F	+	Volume Up
G	▶II	Play / Pause / Power
H	▶▶I	Next / Fast-Forward
I	—	Volume Down
J	I◀◀	Previous / Rewind
K	Reset Button	
L	MIC	Microphone
M		Headphone Jack
N	Lanyard Attachment Loop	
O	Line-In Port	

Music Playback Screen |



	ICON	INDICATION
A	**Record Source**	Built-in Microphone, FM Radio or Line-In
B	**Record Quality**	Indicates the Record Quality, Low Quality, Medium Quality, High Quality
C	**Repeat Mode**	Normal, Random, Repeat One, Repeat All, Repeat Folder, Folder, Shuffle in Folder and A-B Repeat
D	**EQ Mode**	Normal, Bass, Jazz, Soft, Classical, Pop, Rock, User EQ
E	**Sleep**	Sleep Timer is enabled
F	**Auto Power Off**	Auto Power Off function is enabled
G	**Hold**	Hold switch is enabled (controls are locked)
H	**Battery**	Battery power level
I	**Album / Artist / Lyrics / Song Title**	Displays album title, artist name, song title, file name, or lyrics
J	**Track Time**	The total length (play time) of the file
K	**Track Number**	Current track number and total number of tracks available
L	**Play Status**	Play, Pause, Fast Forward, Rewind, Stop, or Record status

Basic Operation

Charging the Battery

Remove the MP330's cap and plug its USB connector directly into an available USB port on your desktop or notebook computer. The MP330's internal Li-ion battery will begin charging. A battery charging indicator will appear in the upper right hand corner of the player's screen. Leave the player plugged in until the battery charging animation stops.

NEVER* plug the MP330 into a USB hub or an external USB port located on a keyboard, monitor or other peripheral. *This can permanently damage your digital music player.
When charging the battery, Please plug the MP330 directly into your computer's built-in USB port or use the Transcend USB Power Adapter (optional).



Power ON

Press and hold the ▶II button to turn on the player. An animated logo will appear, followed by the player status information. After the startup sequence, the Main Menu will be displayed, indicating the MP330 is ready for use.

- *It takes a few seconds for the MP330 to power up.*
- *If the lock icon* *appears on the display while powering on the MP330, this means that the* ◀HOLD *switch is enabled (*◀HOLD*). You must switch off the Hold mode (*◀HOLD*) before you can power on the player.*

Power Off

Press and hold the ▶II button to turn off the MP330.

- *It takes a few seconds to completely power down.*

- *The power off animation will be displayed:*

Play a Song

Press the ▶II button to play a selected music or recording file.

Pause a Song

Press ▶II to pause and un-pause a song or recording during playback.

Next Track

Press ▶▶I to skip to the next available song.

Previous Track

Press I◀◀ to go back to the previous song.

Fast Forward

Press and hold the ▶▶I button to fast-forward.

Rewind

Press and hold the I◀◀ button to rewind.

Increase Volume

Press once or press and hold the + button until you reach the desired volume level.

Decrease Volume

Press once or press and hold the − button until you reach the desired volume level.

Back / Main Menu

Press ⧉ in any mode to enter the Main Menu. The Main Menu gives you access to the MUSIC, RADIO, RECORD modes and the SETTINGS menu.

Hold

When the ◂HOLD switch is enabled, all of the MP330's buttons will be disabled, and cannot accidentally be pressed while in your pocket.

Reset

If the MP330 is not functioning properly, you can reboot by pressing **RESET** for 3 to 5 seconds.

MUSIC Mode

1. Press and hold the ▶II button to power ON the unit. The Main Menu will appear.
   - *If the MP330 is already on, press the ⧉ button to enter the Main Menu.*
2. Use the ⏮ and ⏭ buttons to select "**MUSIC**" and press ▶II.

3. To exit the MUSIC menu, press the ⧉ button.

Playing Audio Files

1. In the MUSIC menu, use ⏮ / ⏭ to select "**Now Playing**" and press ▶II.

2. Select the song you want to listen to with the ⏮ and ⏭ buttons.

3. Press ▶II to begin listening to a music file.

- *While playing a song, press once or press and hold + / − until you reach the desired volume level.*

- *Please see the Specifications section for a list of all music file formats the MP330 supports.*
- *If the music player cannot find any compatible files, a "No Music Files" message will be displayed.*

Repeat Mode

There are six Repeat modes to choose from:

Normal	(plays all music files available one time, in consecutive order)
Shuffle	(continuously repeats playback of all music files available, in random order)
Repeat One	(continuously repeats the current song)
Repeat All	(continuously repeats playback of all music files available, in consecutive order)
Repeat in Folder	(continuously repeats playback of all music files in a folder, in consecutive order)
Normal in Folder	(plays all music files in a folder one time, in consecutive order)
Shuffle in Folder	(plays all music files in a folder, in random order)

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use / to select "**Repeat**" and press .

3. Use the / buttons to select a repeat mode and press to confirm.

EQ Mode

There are eight equalizer modes to choose from:

NOR **Normal**, BASS **Bass**, JAZZ **Jazz**, SOFT **Soft**, CLA **Classical**, POP **Pop**, ROCK **Rock**, and HEQ **User EQ**

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use the / buttons to select "**Equalizer**" and press .

3. Use the / buttons to select an equalizer mode. If music is playing, you will instantly hear the difference between each mode through the earphones.

4. Press to confirm the new EQ setting.

User EQ Customization

User EQ allows you to customize the 5-band equalizer to your personal preference.

- In the EQ menu, use / to select "**User EQ**" and press .

- Use the / buttons to switch between 5 bands: 250Hz, 500Hz, 1KHz, 5.5KHz, and 8.2KHz. The "ALL" setting move all 5 bands up or down together.

- Press / to increase or decrease levels of each frequency range.

- Press to save the new User EQ settings.

SRS WOW MODE

There are four equalizer modes to choose from:

, **SRS WOW**, **SRS 3D**, **Focus**, **TruBass**

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use the / buttons to select "**SRS WOW MODE**" and press .

- **SRS WOW**：There is only one equalizer mode available.
  - Use / to select "***SRS* WOW**" and press .

- **User Setting :** There are three equalizer modes to choose from that allow you to customize the "SRSWOW" Equalizer Mode to your personal preference.
  - Use / to select "**User Setting**" and press .

  - Use the / buttons to select an equalizer mode and press .

  - Use the / buttons to adjust range: from 1 to 10.

  - Press to save the new User EQ settings.

A-B Repeat

This function will create bookmarks in order to repeat a certain sequence.

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use the / buttons to select "**A-B Repeat**" and press .

3. Press the button once to mark the beginning of the portion you wish to repeat.
4. Press the button again to mark the end of the section you wish to repeat.
5. The marked section of the track will playback in a continuous loop.
6. Press the button once more to stop the A-B repeat function.

Adding a Song to My Playlist

This function will add your favorite songs into My Playlist.

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use / to select "**Add to My Playlist**" and press .

Lyrics Sync

This feature displays the lyrics of a song (if available) simultaneously during music playback.

Note: For Lyrics Sync to work, an ".LRC" file with the exact same file name as its corresponding .MP3 song must be transferred to the MP330 in the same folder as the MP3 file.

Ex: If the MP3 file is "GM-Last_Christmas.mp3", the LRC lyrics file must be named "GM-Last_Christmas.lrc"

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use / to select "**Lyrics Sync**" and press .

3. Use / to switch between "**Enable**" or "**Disable**" and press . If lyrics are disabled, the album, artist, and song title information will be displayed during music playback.

Delete

This function will delete the file from the internal memory.

1. While playing a song in MUSIC mode, press the button to open the Options menu.
2. Use / to select "**Delete**" and press .

3. Navigate to the file you want to delete with the /

4. Use the / buttons to highlight "**Yes**" and press to remove the file from the internal memory or select "**No**" to go back.

My Playlists

For quick and easy playback of your favorite songs, the MP330 supports custom playlist builder.

1. In the MUSIC menu, use ⏮ / ⏭ to select "**My Playlists**" and press ⏯.

2. Use ⏮ / ⏭ to select "**My Playlist**" and press ⏯.

3. Use the + / − buttons to move up and down the list of files.



4. Highlight the file you want to play and press ⏯

Remove a song from My Playlist

1. In the MUSIC menu, use ⏮ / ⏭ to select "**My Playlists**" and press ⏯.

2. Use ⏮ / ⏭ to select "**Remove from list**" and press ⏯.

3. Use the + / − buttons to move up and down the list of files, highlight the file you want to remove from the playlist and press ⏯



Clear Playlist

The Clear Playlist is the quick way of deleting the all songs of playlist

1. In the MUSIC menu, use ⏮ / ⏭ to select "**My Playlists**" and press ⏯.

2. Use the ⏮ / ⏭ to select "**Clear Playlist**" and press ⏯.

3. Use the ⏮ / ⏭ buttons to highlight "**Yes**" and press ⏯ to clear playlist or select "**No**" to go back.

Import Playlist (*.m3u)

For quick and easy playback of your favorite songs, the MP330 supports M3U playlist import. The MP330 can store up to 10 m3u playlists, with naming convention LIST0.m3u, LIST1.m3u, LIST2.m3u… LIST9.m3u.

1. Insert the MP330 into an available USB port on your computer.

2. Open Windows Media Player and begin transferring the desired songs from your MP330 drive to the Windows Media Player List pane.



3. When your playlist is complete, click the "**Unsaved list**" button at the top of the List pane and click "**Save list as**" to open the "**Save As**" dialog box. (Wording for this action may vary depending on your version of Windows Media Player)



4. The playlist must be saved to the top layer of the MP330 drive. Type the name of the playlist using the naming convention LIST0.m3u, LIST1.m3u, LIST2.m3u… LIST9.m3u, and save using the m3u file format.



5. Safely remove the MP330 from the computer using the steps found in the section **Disconnecting from a Computer**.
6. In the MUSIC menu, use ⏮ / ⏭ to select "**Playlists (*.m3u)**" and press ⏯.

7. Use the ⏮ / ⏭ to select "**Import (*.m3u)**" and press ⏯.

8. Use ⏮ / ⏭ to select the LIST number corresponding to the same LIST number that the file was saved as in step 4 and press ⏯.

Playlist Playback (*.m3u)

1. In the MUSIC menu, use ⏮ / ⏭ to select "**Playlists (*.m3u)**" and press ⏯.

2. Use ⏮ / ⏭ to select “**List**” and press ⏯.

3. Use ⏮ / ⏭ to select the LIST you want to play and press ⏯.

4. Use the ＋ / － buttons to move up and down the list of files, highlight the file you want to play from the playlist and press ⏯.

File Navigator

The File Navigator is a fast and convenient way of moving between tracks, files and folders.

1. In the MUSIC menu, use ⏮ / ⏭ to select “**File Navigator**” and press ⏯.

2. A list of available files or folders will be shown.
3. Use the ＋ / － buttons to move up and down the list of files.



4. Highlight the file you want to play and press ⏯
5. To enter a folder or subfolder, highlight it and press either ⏯.
6. To exit a folder, press ⏎ or select the ↩ icon and press ⏯ to move up one folder level

RADIO Mode

Listening to the Radio

1. Plug in the earphones . (Earphones must be plugged-in to listen to the Radio)
2. Press the button to enter the Main Menu.
3. Use the / buttons to select "**RADIO**" and press .

4. The current FM radio frequency will be displayed.

- *The first time you use the Radio, the MP330 will automatically scan all frequencies and save the 20 strongest stations as channel presets (CH).*

Selecting a Radio Station

To manually select a radio station, press / (the FM frequency will increase or decrease in 0.1MHz increments) until you reach the desired station. Alternatively, you can press and **hold** or to auto-scan for the next available station.

Recalling a Saved Station

Use the button to scroll through each channel. (CH01~CH20)

Recording the Radio

1. Select a radio station that you want to record.

2. Press and hold the button for 2 seconds to begin recording the station.
3. An automatically generated file name for your recording will appear.

4. Press to pause the recording, and press again to resume.

5. Press / to finish the recording and return to the RADIO mode.

- *FM Recordings are named and numbered in this format: "**YearMonthDayF##.WAV**"*

Ex: "20101F12.WAV " would be the twelfth FM recording made on January 1st , 2012.

- *FM recording are saved in the /**RECORD/FM** folder. Use the File Navigator in MUSIC mode to locate and play back recordings*
- *To adjust the FM recording sample rate, please see "**Settings** / **Record Quality**"*

Channel List

This function will display all saved Radio stations (CH 01 to CH 20).

1. In RADIO mode, press [•\•••] to open the Options menu.
2. Use [⏮] / [⏭] to select "**Channel List**" and press [⏯].

3. A list of all saved Radio stations will be shown.

Save Station

The MP330 lets you save your 20 favorite radio stations (CH 01 to CH 20).

To save current station:

1. In RADIO mode, press [•\•••] to open the Options menu.
2. Use [⏮] / [⏭] to select "**Save Station**" and press [⏯].

Delete

This function will delete the current saved station.

1. In RADIO mode, press [•\•••] to open the Options menu.
2. Use [⏮] / [⏭] to select "**Delete**" and press [⏯].

Delete All

This function resets all saved Radio stations (CH 01 to CH 20). If you use this feature, the next time you enter the **RADIO** mode, the MP330 will automatically re-scan and save the 20 strongest stations.

1. In RADIO mode, press [•\•••] to open the Options menu.
2. Use [⏮] / [⏭] to select "**Delete All**" and press [⏯].

Auto Search

This function will automatically re-scan and save the 20 strongest stations as channel presets (CH).

1. In RADIO mode, press [•\•••] to open the Options menu.

2. Use ⏮ / ⏭ to select “**Auto Search**” and press ⏯.

FM Band

The MP330 allows you choose World FM Band (87.5MHz~108.0MHz) or Japan FM Band (76.0MHz~90.0MHz).

1. In RADIO mode, press ● to open the Options menu.
2. Use ⏮ / ⏭ to select “**FM Band**“ and press ⏯.

3. Use ⏮ / ⏭ to select “**World FM Band**” or “**Japan FM Band**,” then Press ⏯ to confirm.

RECORD Mode

There are two ways to use the player's record functions:

- *Press the* *button to open the Main Menu and select* ***RECORD****.*

- *Press and* ***hold*** *the* *button for 2 seconds in any mode.*

The MP330 supports three different types of recording:

- **Voice Recording**
- **Line-in Recording**
- **FM Radio Recording**

Voice Recording

1. Press and hold the button for 2 seconds in any mode (except Radio) or select **RECORD** from the Main Menu to activate the MP330's built-in microphone and begin voice recording.
2. An automatically generated file name for your recording will appear on the screen.

3. Press to pause the recording, and press again to resume.

4. Press the / button to finish the recording. The player will return to the Main Menu.

- *Voice recordings are named and numbered in this format: "****YearMonthDayM###.WAV****"*

  Ex: "20113M12.WAV "would be the twelfth Voice recording made on January 13th, 2012.
- *Voice recording are saved in the /****RECORD/MIC*** *folder. Use the File Navigator in MUSIC mode to locate and play back recordings*
- *To adjust the recording sample rate, please see "****Settings*** */ **Record Quality**"*
- *For best results, try to position the MP330's Microphone as close as possible to the source of the sound or voice you are recording.*

Line-in Recording

1. Press and hold the ⏺ button for 2 seconds in any mode (except Radio) or select **RECORD** from the Main Menu to activate the MP330's Line-In recording.
2. An automatically generated file name for your recording will appear on the screen.

3. Press ⏯ to pause the recording, and press ⏯ again to resume.

4. Press the ⏺ / ⏏ button to finish the recording. The player will return to the Main Menu.

- *Line-In Recordings are named and numbered in this format: "**YearMonthDayL##.WAV**"*

  Ex: " 20113L12.WAV " would be the twelfth Line-In recording made on January 13th,2012.
- *Line-In recordings are saved in the /**RECORD/LINEIN** folder. Use the File Navigator in MUSIC mode to locate and play back recordings*
- *To adjust the recording sample rate, please see "**Settings / Record Quality**"*

FM Radio Recording

Please see the "Recording the Radio" section in the RADIO mode for detailed instructions..

Settings

1. Press the button to enter the Main Menu.
2. Use the / buttons to select "**SETTINGS**" and press .

3. To exit the SETTINGS menu, press the button.

Record Source

Select between **MIC** (Built-In Microphone), **LINE-IN** (for CD Players or other sources) or **AUTO**(Automatic detection) as the Audio Recording method used by the **MP330**.

1. In the SETTINGS menu, use the / buttons to select "**Record Source**" and press .

2. Use the / buttons to select MIC, Line-In or AUTO and press to confirm.

Record Quality

The quality of an audio recording can be set to **Low**, **Medium**, or **High**. Higher recording quality settings require more memory space to save the recorded WAV files.

1. In the SETTINGS menu , Use the / to select the "**Record Quality**" and press .

2. Use / to switch between "**Low**", "**Medium**", or "**High**" and press to confirm.

Power Saving

In the SETTINGS menu, use / to select "**Power Saving**" and press .

Sleep Timer

This function sets a time delay to automatically power-off the MP330, regardless of playback status.

1. Use / to select "**Sleep Timer**" and press .

2. Use ⏮ / ⏭ to select a Sleep delay time and press ⏯. You can choose from "**Disable**" , "**15 min**", "**30 min**", or "**60 min**". When the selected time is reached, the MP330 will automatically power off.

Auto Power Off

This function sets a time delay to automatically power-off the MP330 after a certain period of time with no user input.

1. Use ⏮ / ⏭ to select "**Auto Power Off**" and press ⏯.

2. Use ⏮ / ⏭ to select a Power Off delay time and press ⏯. You can choose from "**Disable**", "**15 min**", "**30 min**", or "**60 min**". When the selected time is reached, the MP330 will automatically power off

Display

In the SETTINGS menu, use ⏮ / ⏭ to select "**Display**" and press ⏯.

Screen Saver

This function lets you enable/disable the screen saver, choose which screen saver you want to be displayed, and set the time delay for the screen saver to activate. Available screen savers are:

Blank (Displays an all-black screen to save battery life)

Clock (Displays the current real time)

1. Use ⏮ / ⏭ to select the "**Screen Saver**" and press ⏯.

2. Use ⏮ / ⏭ to select a Screen Saver delay and press ⏯. The screen saver will commence whenever this amount of time passes with no button activity. Available delay timers are: "**Disable**", "**10 sec**", "**20 sec**", and "**30 sec**".

3. After you select a Screen Saver time delay, a list of available screen savers will appear. Use ⏮ / ⏭ to select one of the Screen Saver types and press ⏯.



Contrast

The contrast of the OLED display can be adjusted for brighter or darker text. Higher contrast levels will drain the battery faster, while lowering the contrast level will provide better battery life.

1. Use ⏮ / ⏭ to select "**Contrast**" and press ⏯.

2. Use ⏮ / ⏭ to increase or decrease contrast.

3. Press ⏯ to confirm the new contrast level.

Volume Limit

This function lets you enable/disable the volume limit and set a maximum limit level to prevent the volume from exceeding a certain value.

1. In the SETTINGS menu, use the ⏮ / ⏭ buttons to select "**Volume Limit**" and press ⏯.

2. Use ⏮ / ⏭ to select "**on/off**" and press ⏯.

3. If you select "on", press once or press and hold ＋ / － until you reach the desired volume limit level, and press ⏯ to confirm. (待確認)

Date / Time Settings

This option lets you adjust the local date and time.

1. In the SETTINGS menu, use ⏮ / ⏭ to select "**Date/Time Settings**" and press ⏯.

2. Use ⏮ / ⏭ to move between 12/24Hr, Year, Month, Day, Hour, Minute, and Second.



3. Adjust the values of each field with the + / − buttons.



4. Press ▶II to confirm your new time settings.

***Tip:** You can view a full-screen version of the player's internal clock by pressing ⧉ in the Main Menu.*

Language

Set the MP330's display language, including menus, song/album titles, artist names, and lyrics. The player supports 13 User languages.

1. In the SETTINGS menu, use ⏮ / ⏭ to select the "**Language**" and press ▶II.

2. Select your language with the ⏮ / ⏭ buttons and press ▶II to confirm.

Player Info

Display the MP330's firmware version and available memory capacity.

1. In the SETTINGS menu, use ⏮ / ⏭ to select "**Player Info**" and press ▶II.

2. Press any button to return to **SETTINGS** menu.

Driver Installation

Driver Installation for Windows®2000, XP and Vista

No drivers are required. These Windows® Operating Systems have built-in drivers to support the MP330. Plug your MP330 into an available USB port and Windows® will install the necessary files. A "**Removable Disk**" drive with a newly assigned drive letter will appear in the **My Computer** window.

Driver Installation for Mac® OS 10.0 or Later

No drivers are required. Plug your MP330 into an available USB port and your computer will automatically detect it.



Driver Installation for Linux® Kernel 2.4 or Later

No drivers are required. Plug your MP330 into a USB port and mount it.

1. Create a directory for the MP330.

   Example: **mkdir /mnt/MP330**

2. Mount the MP330.

   Example: **mount –a –t msdos /dev/sda1/mnt/MP330**

NEVER format your MP330 in Windows.

Connecting to a Computer

Transferring Files to the MP330

If you want to use your MP330 to listen to music other than the Radio, you must transfer music files to the player. **When the MP330 is connected to a computer it is locked into transferring files**. You will not be able to play or record any music at this time. Please disconnect your MP330 from the computer when you want to use the player.

> ***NEVER** plug the MP330 into a USB hub or an external USB port located on a keyboard, monitor or other peripheral. **This may cause damage to your MP330.** When connecting to a computer, Please plug the MP330 directly into your computer's built-in USB port.*

1. Remove the MP330's cap and plug its USB connector directly into an available USB port on your desktop or notebook computer. While the MP330 is connected to a computer, it can only be used for transferring files. The MP330's rechargeable Li-ion battery will begin charging.



2. When connected to a computer the MP330's screen will display a "**CONNECTED**" message, indicating that files can be loaded onto the player.

- **You cannot play or record music when the MP330 is connected to a computer.**

3. If you are using Windows®, a new Removable Disk drive with a newly assigned drive letter representing the MP330 will appear in the My Computer window.



*Note: "(F:)" is an example drive letter – your "My Computer" window may differ

4. Always disconnect the MP330 from a computer by selecting the **"Safely Remove Hardware"** icon in the Windows® System Tray at the bottom of the computer screen.

- While files are being transferred from a computer to the MP330, the screen will display a "***WRITING…***" message. After files have been successfully transferred, the "***CONNECTED***" message will be displayed again.

- When you copy files or folders from the MP330 to your computer, the player will display a **"*READING…*"** message indicating that files are being transferred to the computer. After files have been successfully transferred, the **"*CONNECTED*"** message will be displayed again.

NEVER unplug the MP330 during file transfer. Unplug the MP330 only when Windows informs it is safe to do so.

Disconnecting from a Computer

Always follow the procedures listed below before you disconnect the MP330.

Disconnecting the MP330 in Windows® 2000, XP and Vista

1. Select the Hardware icon in the system tray.
2. The **Safely Remove Hardware** pop-up window will appear. Select it to continue.

3. A message window will appear stating: “The ‘USB Mass Storage Device’ device can now be safely removed from the system.”

4. Unplug the MP330 from your computer.



Disconnecting the MP330 in Mac® OS 10.0 or Later

1. Drag the Disk icon that corresponds to your MP330 into the trashcan.
2. Unplug your MP330 from the USB port

Disconnecting the MP330 in Linux® Kernel 2.4 or Later

1. Execute **unmount /mnt/MP330** to un-mount the device.
2. Unplug your MP330 from the USB port.

Troubleshooting

If a problem occurs with your MP330, please first check the information listed below before taking your MP330 for repair. If you are unable to remedy a problem from the following hints, please consult your dealer, service center, or local Transcend branch office. We also have FAQ and Support services on our website.

Operating system cannot detect the MP330

Check the following:

- Is your MP330 properly connected to the USB port? If not, unplug it and plug it in again.
- Is your MP330 connected to the Mac keyboard? If so, unplug it and plug it into an available USB port on your Mac computer.
- Is the USB port enabled? If not, refer to the user's manual of your computer (or motherboard) to enable it.

Cannot Power ON

Check the following:

- Is the MP330 connected to your computer? If so, unplug it.
- Is the

switch engaged? ( ). If it is, switch it to the off position ( ).
- Is the battery out of power? If so, please plug the player into a USB port to recharge it. The battery may drain if connected to a computer that is off or in sleep or standby mode. Always ensure the computer is on to charge successfully.

Cannot transfer files to the MP330

Unplug the MP330 from your computer, wait a moment, and plug it back in. If this does not work, use a paperclip or pencil tip to hold down the **"Reset"** button for 3 to 5 seconds.

Buttons aren't working

Is the Hold switch enabled ( )? If so, set it to the off position ( ).

Cannot hear audio playback

- Have you transferred any music files to the MP330? If not, then you must first do so. (Only Mpeg I Layer 3 and WMA files compressed at a rate of 32Kbps–320Kbps, and WAV files are supported.)
- Are the earphones properly connected to the earphones jack? If not, reconnect them.
- Is the volume loud enough? If not, increase the volume level until the music can be heard.

Song/album/artist name is not displayed correctly on the screen

- The default language of the MP330 is English. Please change the player's Language setting to the appropriate language for the content you are trying to display. ***EX: if your player's language is set to English and you want to display Japanese characters, you must first select "Japanese" in the Settings / Language menu to display the Japanese text correctly.***
- ID3 tag information has display priority on the screen of the MP330. You can modify the ID3 tag by using Windows Media Player or Winamp.

- If the ID3 tag is empty, just the file name will be displayed on the screen.

Cannot RECORD voice, Line-In, or the FM radio

To make sure recorded files do not get lost, two safety mechanisms are built into the MP330:

- If remaining battery capacity is less than 10%, you cannot enter the RECORD Mode.
- While recording, if the remaining battery capacity goes **below 10%** the MP330 will automatically stop and save the recording.

Track playback sounds intermittent

Unplug the earphones and plug them back in again to make sure they are securely connected.

MP330 powers off automatically

The MP330 features **SLEEP Mode** and **Auto Power Off** functions, which are power-saving features. You can preset your MP330 to power-off automatically. Please refer to the **SETTINGS** section for more information.

MP330 just isn't working properly

If your MP330 ever stops working properly, or locks up, try powering it on and off a few times, if this does not correct the problem you can **Reset** the MP330 by using a paperclip or pencil tip to hold down the "**Reset**" button for 3 to 5 seconds.

Cannot find the file that was just copied to the MP330

Re-copy the file and refer to the "**Disconnecting from a Computer**" section to remove the MP330 after the copy process is completed.

A File that was just deleted still appears

Re-delete the file and refer to the "**Disconnecting from a Computer**" section to remove the MP330 after the delete process is completed.

MP330 does not operate after formatting in Windows®

Formatting the MP330 using the "Quick Format," or "Full Format" option in Windows® erases the default system information that the MP330 requires to operate. To re-install the system information, please visit **http://www.transcend-info.com/Support/DLCenter/** and download a Firmware Update for your MP330.

How do I find out what Windows Media Player version I am using?

- Open your Windows Media Player program.
- Click on the **"Help"** menu and select the **"About Windows Media Player"** option.
- The version of your Windows Media Player will be displayed on the computer screen.

Lyrics Sync: Why can't I see the words of the song I am listening to?

For detailed Lyrics Sync instructions, please see the FAQ section on our website at:
http://www.transcend-info.com/Support/FAQ/

An "Insuffucient Power" message is displayed on the screen

If your MP330 displays an "Insufficient Power" message, this means the device supplying USB power to your digital music player is not outputting stable or adequate voltage to charge the player's internal battery (usually a result of a USB hub or extension cable used. This message does not indicate a problem with the music player.

Plug the MP330 directly into your computer's USB port or a Transcend USB Power Adapter to properly charge its internal battery.

Specifications

Size (L x W x H):	85 mm × 25.5 mm × 11.5 mm
Weight:	25g
Music Formats:	MP3, WMA and WAV
Recording Format:	IMA_ADPCM (WAV)
Estimated Battery Life:	12 hours (fully charged battery)
Compression Rates:	32Kbps to 320Kbps
Signal-to-Noise Ratio:	≥ 90dB
Certificates:	CE, FCC, BSMI
Warranty:	2-years

Ordering Information

Device Description	*Memory Size*	*Transcend P/N*
MP330 Digital Music Player(WHITE)	8GB	TS8GMP330W
MP330 Digital Music Player(BLACK)	8GB	TS8GMP330K
MP330 Digital Music Player(PINK)	8GB	TS8GMP330P

Recycling & Environmental Considerations |



Recycling the Product (WEEE): Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potential negative consequences on the environment and human health.



Battery Disposal: Your product contains a built-in rechargeable battery covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.

Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

For products with non-exchangeable built in batteries: The removal of (or the attempt to remove) the battery invalidates the warranty. This procedure is only to be performed at the end of the product's life.

Transcend Limited Warranty

"Above and Beyond" is the standard we set ourselves for customer service at Transcend. We consistently position ourselves to be significantly above the industry norm, which is all part of our commitment to Customer Satisfaction.

All **Transcend information, Inc. (Transcend)** products are warranted and tested to be free from defects in material and workmanship and to conform to the published specifications. During the warranty period should your Transcend MP330 fail under normal use in the recommended environment due to improper workmanship or materials, Transcend will repair the product or replace it with a comparable one. This warranty is subject to the conditions and limitations set forth herein.

Duration of Warranty: The Transcend MP330 is covered by this warranty for a period of two (2) years from the date of purchase. Proof of purchase including the date of purchase is required for warranty service. Transcend will inspect the product and decide whether to repair or replace it. Transcend reserves the right to provide a functional equivalent or refurbished replacement product.

Limitations: This warranty does not apply to product failure caused by accidents, abuse, mishandling, improper installation, alteration, acts of nature, improper usage, or problems with electrical power. In addition, opening or tampering with the product casing, or any physical damage, abuse or alteration to the product's surface, including all warranty or quality stickers, product serial or electronic numbers will also void the product warranty. Transcend is not responsible for recovering any data lost due to the failure of a flash memory device. Transcend's MP330 must be used with devices that conform to the recommended industry standards. Transcend will not be liable for damages resulting from a third party device that causes the Transcend MP330 to fail. Transcend shall in no event be liable for any consequential, indirect, or incidental damages, lost profits, lost business investments, lost goodwill, or interference with business relationships as a result of lost data. Transcend is also not responsible for damage or failure of any third party equipment, even if Transcend has been advised of the possibility. This limitation does not apply to the extent that it is illegal or unenforceable under applicable law.

Disclaimer: The foregoing limited warranty is exclusive. There are no other warranties, including any implied warranty of merchantability or fitness for a particular purpose. This warranty is not affected in any part by Transcend providing technical support or advice.

Online Registration: To expedite the warranty service, please register your Transcend Product within 30 days of purchase. ***Register online at http://www.transcend-info.com/Member/Register.asp***

Transcend®

Transcend Information, Inc.

http://www.transcend-info.com/

*The Transcend logo is a registered trademark of Transcend Information, Inc.
*The specifications mentioned above are subject to change without notice.
*All logos and marks are trademarks of their respective companies.